

# UNIVERSAL CALIPER

DATA  
OUTPUT

working with stands


working with measuring jaws



1125-600





- Buttons: on/off, set, mm/inch, ABS, preset (+, -)
- Automatic power off, move the digital unit to turn on power
- Battery CR2032
- Data output
- Made of stainless steel
- Optional accessory: data output cable (code 7306-20, 7302-SPC5A/SPC5B, 7305-SPC2A)




Code	Range*	Resolution	Accuracy
1125-600	0-600mm/0-24"	0.01mm/0.0005"	±0.05mm

\*The range changes according to different points

## Half disk points (included)





Measuring external groove diameter with flat measuring face (depth  $h1 \leq 2.5\text{mm}$ )



Measuring internal groove diameter with spherical measuring face (depth  $h2 \leq 7.5\text{mm}$ )



## Conical points (optional)



Measuring center distance

Code  
1125-T101


## Round shoulder points (optional)



Measuring inside diameter

Code  
1125-T102




## Flat shoulder points (optional)




Measuring outside diameter

Code  
1125-T103


## Spherical points (included)



## Point sleeve (optional)





Code  
1125-T104





Working with multifunctional points, ball points and screw thread points



## Stands (included)



## Depth stop (included)



## Measuring jaws (included)



## Multifunctional points 7392 (optional, next page)



## Ball points 7391 (optional, next page)



## Screw thread points 7381, 7321 (optional, next page)

